



Passive Reservoir Monitoring by Use of Inter-well Tracers

Olaf Huseby
VP Technology & Interpretation, Restrack



SPE Webinars are Sponsored by:

SPE
SPE Foundation



Poll Question



What is your job title?



Poll Question



Who is your employer?



Poll Question



How many years of experience do you have?



Poll Question



What geographic region are you from?





Dr. Olaf Huseby
VP Technology & Interpretation,
Restrack



Overview



- **Introduction / recap of inter-well tracer technology**
- Tracer chemicals and lab
- Interpretation options
- Field examples reservoir information from tracers
- EOR applications
- Questions and discussion



30 years of tracer development




1950 – 1970	Use of radioactive tracers in O&G and ground water studies
1971-	Chemical tracer tests developed to evaluate residual oil saturation inter-well (PITT) and single well tests (SWCTT)
1991 –	North Sea offshore water, gas and WAG injection implementation lead to development of chemical water and gas tracers tracer development and application.
2012 –	Increased interest in EOR projects spur further development of partitioning tracers to measure oil saturation (single well and inter-well)



9

Basic tracer concept



- Injection water is "colored" by tracers
- Water from specific injector identified
- Sealing / non-sealing faults
- Topology of the reservoir
- Tracers can explain unexpected water breakthrough



10

Tracer chemicals and lab



- Introduction / recap of inter-well tracer technology
- **Tracer chemicals and lab**
- Interpretation options
- Field examples reservoir information from tracers
- EOR applications
- Questions and discussion



11


Chemical tracers




Tracers available to O&G reservoirs:

- Strict requirements for HSE, stability, temperature and phase behavior
- Limited number of tracers available
- Gas tracers are typically fluorinated hydrocarbons and water tracers are typically fluorinated organic acids
- For oil/water partitioning tracers: stability and suitable partitioning is challenging

Benzoic acid



Fluorinated Benzoic acid



12

Gas and water sampling



- Production sampling required for gas and water tracers
- Flow line or test separator samples may be used
- For shipment from field site standard water bottles can be used
- For gas tracers unpressurized sample tubes are advantageous over pressurized cylinders




Unpressurized sample tubes



Pressurized samples

13

Ultra sensitive tracer analysis development



14

Impact of detection limits




Illustration of investigation area for a $TQF=1e6 \text{ m}^3$ (corresponding to limit of detection of 5 ppb) and a $TQF = 1e8 \text{ m}^3$ (corresponding to limit of detection of 50 ppt) and the same amount of tracer injected

- Detection limit has significant impact on required tracer injection mass. If 50 kg is needed to investigate a field at 50 ppt, 5000 kg is needed for the same investigation at 5 ppb
- Off-site analysis provide the best detection limits whereas on-site analysis has shorter turn-around time

15

Interpretation options



- Introduction / recap of inter-well tracer technology
- Tracer chemicals and lab
- **Interpretation options**
- Field examples reservoir information from tracers
- EOR applications
- Questions and discussion



16

Residence time distribution (RTD) analysis





Moments of the distribution:

$$m_0 = \int_0^{\infty} E(t) dt$$



$$m_1 = \int_0^{\infty} t \cdot E(t) dt$$

Swept volume: $V_s = Q_i m_1 / m_0$



17

Characterize the heterogeneity



- Heterogeneous flow yields curve far from diagonal
- Homogeneous flow yields close to diagonal curve
- Area between diagonal and curve gives Lorentz coefficient



18

Field examples





- Introduction / recap of inter-well tracer technology
- Tracer chemicals and lab
- Interpretation options
- **Field examples reservoir information from tracers**
- EOR applications
- Questions and discussion




19

Quantification of heterogeneous flow (carbonate)



20

Tracers to assess significant effect of polymer



After Huseby; Clemens; Lueftenecker; Puls and Zarruk, IEA's 37th EOR Workshop & Symposium, Rueil Malmaison, France, 2016


- Methodology:
 - inject tracers before polymer and find sweep volume
 - repeat tracer test after polymer flood, find new sweep volume and compare
- Tracer injections (2kg) in S-81 and SC-1
- Legacy tracer (2000 kg) in S-81

21

Main flow directions and sweep volumes




- Post-polymer sweep almost three times that of pre-polymer sweep
- Main flow directions and allocation of injection water also found from the tracer curves



22

Heterogeneity of flow




- Flow before polymer more heterogeneous than flow after polymer
- Clear indication of effect of polymer




Well	Tracer	Lc
P-12	SCN-	0.39
P-12	IFE-WT-11	0.27
P-13	IFE-WT-11	0.11
P-14	IFE-WT-11	0.16
P-21	IFE-WT-12	0.22

23

Case: Bypassed oil detected by tracers




- Assumed source of water was wrong.
- Large potential un-swept oil volume detected from tracers and water injected in I-A was re-routed to injector B.
- **Close Injector A to produce un-swept oil**




24



Basecase: no cross-channel movement



Corrected case allow for cross-channel movement



Gas tracers for WAG tracing





In P-29 gas tracers injected in three separate WAG cycles in P-28 arrive simultaneously. A gas tracer injected in P-25 arrive before GOR increases.



Interpretation: P-25 tracers moves with oil / associated gas - P-28 tracers are mixed in an attic gas volume

27

Simulation of Snorre WAG attic volume



- Adding an attic gas storage volume to the simulation case, it was possible to match the tracer data
- Qualitative interpretation verified by simulation



28

EOR applications



- Introduction / recap of inter-well tracer technology
- Tracer chemicals and lab
- Interpretation options
- Field examples reservoir information from tracers
- **EOR applications**
- Questions and discussion



29

Oil saturation from tracer data



Simultaneous injection of partitioning and passive water tracer




The time delay of partitioning tracer depends on oil saturation (S_o) and the tracer's oil/water partitioning coefficient K ($K=C_o/C_w$)

$$S_o = \frac{t_p - t_w}{t_p - t_w(K - 1)}$$




30


SWCTT - principle




Ester (partitioning tracer) is injected in watered-out zone (1 day)



Ester and secondary tracer is produced (2 days)



Ester partly hydrolyses to alcohol during shut-in (2-3 days)



31


Sor - Partitioning Interwell Tracer Test - PITT




Partitioning tracer (red) and water tracer is co-injected



Partitioning tracer time delay gives amount of oil present



Partitioning tracer (red) is delayed if oil is present



32

Water, surfactant and SWCTT injection rig-up



- Spot SOR measurements
- Pre and post EOR verification
 - ASP / surfactant
 - low salinity
- Connate water
- Fractional flow




33

SWCTT production rig-up and on-site laboratory




- Produced water samples must be analyzed on-site to reduce hydrolysis
- Accurate injection and production rates measurements are important
- Mobile lab with all required instrumentation



34

SWCTT results, EOR method evaluation




	Sea-water	Low salinity	Surfactant
Ester (EtAc) peak	276+/-10	196+/-10	127+/-7
Alcohol (EtOH) peak	150+/-7	107+/-7	82+/-5
Saturation estimate	0.21+/-0.02	0.21+/-0.03	0.14+/-0.03

$$S_o = \frac{V_p - V_w}{V_p + V_w(K - 1)}$$



Ref: IPTC 17951 35

Field case, PITT with three partitioning tracers.



- Oil saturation is given from time delay of partitioning tracers vs. the non-partitioning tracer by the relation

$$S_o = \frac{t_p - t_w}{t_p - t_w(K - 1)}$$

- S=0.19, 0.19, 0.20 from partitioning tracers 1, 2 & 3
- Same results as SWCTT

- Challenging to find functioning PITT tracers
- Newly patented PITT tracers tested in three carbonate and sandstone reservoirs (SPE 164059, EAGE-IOR Symposium 2015, SPE-ATW 2016 on tracers)



Method	SWCTT	PITT
SOR (%)	21 +/- 1	19-23

36

Summary and outlook



- **Current status:**
 - Tracer technology is well-proven with many applications world wide
 - Versatile methodology used for reservoir surveillance, production / injection optimization and EOR
 - Provides conclusive flow information
 - Simple in terms of operations and logistics
 - Manual sampling requirements
 - Limited number of tracers available due to harsh reservoir conditions
- **Further developments and research needs:**
 - automatic sampling
 - simplified / on-site analysis
 - on-line analysis (?)
 - nano materials (?) to protect tracers from harsh conditions may provide unlimited number of tracers (e.g. DNA tracers)



37

Questions?

Thank you!

